1911 'TIMELESS' TOY MODEL ASSEMBLY GUIDE





Parts List

- A. Pin
- B. Slide lock
- C. Slide
- D. Base
- E. Replica rounds
- F. Magazine
- G. Trophy stand
- H. Spring

HOW TO:





Insert pin (A) into spring (H).
Push firmly into front bottom of slide. Hold spring down with finger to avoid popping out.



2 Combine the slide (C) with the base (D) by pushing them together





Drop Slide lock (part B) into hole with lever part facing right. Push slide back to where it matched the small indent and let it drop into place. Your toy miniature 1911 should easily move back and forth.



Insert dummy rounds (E) into magazine (F). Push magazine into bottom of grip. Display on stand (G)

DISCLAIMER:

This is a miniature closed barrel toy model. Never take to public places. Keep on display stand at all times. Owner accepts all legal responsibilities.

COLLECT ALL OUR
MINIATURE TOY MODELS
AT GORTGUNS.COM

FOR A CHANCE TO BE FEATURED
ON OUR SOCIAL MEDIA, USE
#GOATGUNS TO TAG US ON
INSTAGRAM @GOAT.GUNS