


Goat Gun AUG Assembly Guide



Parts List

- | | | |
|-----------------------|----------------------|------------------|
| A. Left housing body | E. Stock | I. Display stand |
| B. Right housing body | F. Charging handle | |
| C. Picatinny rail | G. Magazine | |
| D. Barrel grip | H. Non-firing rounds | |



Scan for video

Hardware List

- | |
|-----------------------------|
| [1] sling ring |
| [3] screws |
| [1] screwdriver with magnet |



- 1** Place picatinny rail (C) onto left housing body (A).



- 2** Insert charging handle (F) into left housing body (A) and slide forward.



- 3** Insert barrel grip (D) into holes at bottom of housing body (A).



- 4** Place sling ring into provided hole. Snap right housing body (B) into place.



- 5** Insert screws into the 3 holes on the right side of housing body (B).



- 6** Push together stock (E) and housing body.



- 7** Load non-firing rounds (H) into magazine (G). Slide magazine until it clicks into place, and show off your Goat Gun on the display stand (I).